



[Adobe PDF Downloadable Version of Article](#)

Loading and Unloading



The rifle can be loaded either one at a time or 5 cartridges at a time via a stripper clip. Both are done through the top.



To remove the magazine you depress the magazine catch located forward of the trigger inside of the trigger guard.



Safety



Figure 4 shows the safety in the FIRE position enabling the rifle to be fired.



Figure 5 shows the safety in the SAFE position.

[Adobe PDF Downloadable Version of Article](#)

Copyright 2003, 2004 © Jamie Mangrum

All material on web pages under the domains surplusrifle.com, surpluspistol.com, or surplusfirearm.com, and CD-ROMS produced by Surplusrifle.com, unless otherwise stated, are the property of Jamie Mangrum. These materials are protected by copyright and other intellectual property laws. Information received through this website may be displayed and printed for your personal, **noncommercial use only**. You may make copies of the materials available through this website, solely for your personal, **noncommercial use**, and only if you preserve any copyright or other notices contained in or associated with them. You may not see the materials found on this website.

Copyright 2003, 2004 © Jamie Mangrum