



[Adobe PDF Downloadable Version of Article](#)

Loading and Unloading



The rifle can be loaded either one at a time or 5 cartridges at a time via a stripper clip. Both are done through the top.



The magazine release is inside of the trigger guard positioned to the front of the trigger. It can be quickly and easily depressed to drop the magazine by pressing up on the lever.





Instead of a cocking piece style safety, there is a lever on the left rear of the receiver that can be actuated by pulling it to the rear and snapping/locking it down.



Adjusting the sights are easily accomplished by sliding the elevation up and down the gradient.





There is also a small micro adjustment on the rear sight that I have not seen on any other stock surplus military rifle, that I really like. You can adjust the rifle (as shown in Sight 3) to a very granular level by turning the "*backsight, fine adjustment worm wheel*" one click, each click represents a change of only 5 yards!

[Adobe PDF Downloadable Version of Article](#)

Copyright 2003, 2004 © Jamie Mangrum

All material on web pages under the domains surplusrifle.com, surpluspistol.com, or surplusfirearm.com, and CD-ROMS produced by Surplusrifle.com, unless otherwise stated, are the property of Jamie Mangrum. These materials are protected by copyright and other intellectual property laws. Information received through this website may be displayed and printed for your personal, **noncommercial use only**. You may make copies of the materials available through this website, solely for your personal, **noncommercial use**, and only if you preserve any copyright or other notices contained in or associated with them. You may not see the materials found on this website.

Copyright 2003, 2004 © Jamie Mangrum